













ASSEMBLY INSTRUCTIONS FOR DINING CHAIR

FC-12











ALL THE COMPONENT AS FOLLOW

1




2


 AX2 BX1

 GX4

 FX4

 HX4


 DX1

 EX2

 FX2

 IX2

3

4


 CX1

 GX4

 KX2